



Zyxel firewall usg 50 Disassembly

ZyXEL Firewall Disassembly Guide Model USG 50

Written By: Eneider Colina



INTRODUCTION


Disassembly Guide



TOOLS:


- [Phillips screwdriver](#) (1)
-

Step 1 — Removing the screws




- screws
- Rack mount kit (ears)

Step 2 — Removing DB9 Connector




- To remove the cover it is necessary to disconnect the DB9 connector

Step 3 — Removing the lid




- The cover slides out


Step 4 — Motherboard



- To remove the motherboard it is necessary to remove the 6 screws that fasten it to the chassis
- If the machine does not save the time, you can replace the battery

 CR2032 3 Volt Lithium

Step 5 — Chassis



- Rubbers prevent the plate from contacting the chassis.

Para reensamblar tu dispositivo, sigue estas instrucciones en orden inverso.

This document was last generated on 2017-06-20 11:10:18 AM.